



Wet Method

December 2004

Installation Guide: Basic

Application type: Wet method

1. Make sure you have all the tools you need for the installation.
 - Squeegee
 - A mixture of 3/4 water and 1/4 of 99% Isopropyl Alcohol.
 - Paper Towels
 - Razor Knife
2. Clean the surface that you intend to install the decal on.
It won't hurt to clean it several times, as the cleaner the surface is the better the decal will stick.

NOTE. The decal has 3 layers, backing paper, decal, and premask.

3. Lay the decal on a table or flat surface, face down (premask down).
4. Peel the backing paper off going in one direction exposing the adhesive of the decal.
Do this slowly so you can make sure it all comes off.
5. Spray the area of installation with the mixture from above until it is wet. You can also spray the sticky side of the decal.
6. Place the decal on the area desired.
7. Take the squeegee and swipe the decal firmly three or four times in a left to right or top to bottom motion.
8. Let it set for 1 minute then remove the premask slowly in one direction.

Disclaimer: *The techniques described here are intended as an overview of the vinyl manufacturer's suggested installation and removal methods. APE Wraps accepts **NO** responsibility for property damage, injury, or any other liability resulting from the use of these methods, or the installation of decals on any surface.*